

Pascal 3.0

Documentation Guide

and Master Index

for the HP 9000 Series 200 Computers

Manual Part No. 98615-90015

© Copyright 1984, 1985, Hewlett-Packard Company.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another language without the prior written consent of Hewlett-Packard Company. The information contained in this document is subject to change without notice.

Use of this manual and flexible disc(s) or tape cartridge(s) supplied for this pack is restricted to this product only. Additional copies of the programs can be made for security and back-up purposes only. Resale of the programs in their present form or with alterations, is expressly prohibited.

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in paragraph (b)(3)(B) of the Rights in Technical Data and Software clause in DAR 7-104.9(a).



Hewlett-Packard Company
3404 East Harmony Road, Fort Collins, Colorado 80525

Printing History

New editions of this manual will incorporate all material updated since the previous edition. Update packages may be issued between editions and contain replacement and additional pages to be merged into the manual by the user. Each updated page will be indicated by a revision date at the bottom of the page. A vertical bar in the margin indicates the changes on each page. Note that pages which are rearranged due to changes on a previous page are not considered revised.

The manual printing date and part number indicate its current edition. The printing date changes when a new edition is printed. (Minor corrections and updates which are incorporated at reprint do not cause the date to change.) The manual part number changes when extensive technical changes are incorporated.

June 1984...First Edition

March 1985...Update.

Index was updated to include references to HP 46020 Mouse installation and use.

April 1985...First Edition with Update.

This revision includes the March 1985 update.

Warranty Statement

Hewlett-Packard products are warranted against defects in materials and workmanship. For Hewlett-Packard Fort Collins Systems Division products sold in the U.S.A. and Canada, this warranty applies for ninety (90) days from the date of delivery.* Hewlett-Packard will, at its option, repair or replace equipment which proves to be defective during the warranty period. This warranty includes labor, parts, and surface travel costs, if any. Equipment returned to Hewlett-Packard for repair must be shipped freight prepaid. Repairs necessitated by misuse of the equipment, or by hardware, software, or interfacing not provided by Hewlett-Packard are not covered by this warranty.

HP warrants that its software and firmware designated by HP for use with a CPU will execute its programming instructions when properly installed on that CPU. HP does not warrant that the operation of the CPU, software, or firmware will be uninterrupted or error free.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

* For other countries, contact your local Sales and Support Office to determine warranty terms.

Documentation Guide and Master Index

Introduction

This guide takes you on “sight-seeing tours” of the Pascal 3.0 manuals. Here is what it contains:

- A list of the manuals in this set.
- A “sight-seeing tour” of each manual.
- A look at the Master Index.

Pascal 3.0 Manuals

Here are the manuals provided with the Pascal 3.0 Workstation system:

- *Pascal 3.0 User's Guide*
- *An Introduction to Programming and Problem Solving with Pascal*
- *Pascal 3.0 Workstation System*
- *Pascal 3.0 Procedure Library*
- *Pascal 3.0 Graphics Techniques*
- *HP Pascal Language Reference for Series 200 Computers*
- *MC68000 User's Manual*

Individual Manual “Tours”

The following paragraphs describe the purpose and contents of each manual.

Note

You are highly encouraged to pick up and leaf through each manual as you read through its description. This exercise will help you to quickly familiarize yourself with their content and organization.

Installation Guide (for your model of computer)

One of these manuals is shipped with your computer (*not* with the Pascal System). It describes setting up computer hardware and peripheral devices. It will take you up to the point where you are ready to load the Pascal system into the computer. These manuals are mainly task-oriented manuals. Here is what the manuals will help you to do:

- Put the computer hardware together.
- Configure and install memory and interface cards.
- Configure and install peripheral devices (such as printers).
- Run self-tests.

Pascal 3.0 User's Guide

This begins where your computer's *Installation Guide* left off. It describes how to load the Pascal System and get it "up and running." It also takes you on a "tour" of the system and its subsystems, as well as shows you how to enter and run a short Pascal program. This manual is also a task-oriented manual.

- Chapter 1 discusses a "little-known secret to success." (If you don't read the chapter, it will be still "little-known.")
- Chapter 2 shows you how to load the Pascal system.
- Chapter 3 shows you how to prepare blank discs for use and how to make back-up copies of the system discs.
- Chapter 4 describes using the keyboard and display. You need only read the section that describes your computer's keyboard.
- Chapter 5 shows you how to begin using commands.
- Chapter 6 introduces you to the Editor, which you will use to enter a document.
- Chapter 7 introduces you to the Filer, which you will be using to manage the files in which you will be storing documents and programs.
- Chapter 8 describes using the Compiler, which you will be using to transform a source program into a form that the computer can execute.
- Chapter 9 briefly discusses the Assembler, Librarian, and Debugger subsystems.
- Chapter 10 is devoted to helping you set up your programming "environment."
- In Chapter 11, you will be entering, storing, compiling, and running a short Pascal program.
- The Task Reference briefly summarizes the steps for common procedures.
- There is also a subject index at the rear of this manual.

An Introduction to Programming and Problem Solving with Pascal

This is a textbook that will teach you the Pascal programming language. You should read it if you have not previously programmed using the Pascal language before, or if you have never programmed before. It is a combination of task-oriented information (such as discussions of how to solve particular programming problems) and object-oriented information (such as descriptions of reserved words and standard procedures).

- The STYLE CLINICS section lists the programming style tips given throughout the book.
- Chapter 1 describes the steps involved in developing programs in any computer language.
- Chapter 2 takes a closer look at developing algorithms. A thorough understanding and *application* of these principles will help you to become a good programmer as quickly as possible. You should memorize and follow the maxim:

"Think First, Code Later."

- Chapters 3 through 10 present lots of advice and examples of Pascal programming.
- Chapter 11 presents a well organized summary of the "program design methods" that have been taught in the book.
- Appendices include the following: syntax diagrams, a list of standard identifiers, character sets, bibliography, selected answers to exercises, and subject index.

Pascal 3.0 Workstation System

This manual describes the HP Series 200 Pascal Workstation system. By reading it, you will learn how to use individual commands as well as how to use the subsystems (Editor, Filer, etc.). The chapters that describe the subsystems first take a task-oriented approach at introducing you to using the subsystem, and then provide an object-oriented discussion of each command at the end of the chapter. The last two chapters provide more task-oriented discussions of standard and special configurations and “non-disc” mass storage devices.

- Chapter 1 begins with an overview of the manual. It then provides a quick reference and detailed descriptions of Main Level commands.
- Chapter 2 describes the File System of the Pascal Workstation system, and provides some notes about file access from Pascal programs.
- Chapters 3 through 8 describe the subsystems of the Workstation system: Editor, Filer, Pascal Compiler, Assembler, Librarian, and Debugger. The first part of each chapter describes using the subsystem, while the latter part describes each command. Pay special attention to the concept of program *modules*, because the system itself is composed of modules. An understanding of these structures will greatly increase your ability to use the system to the fullest extent.
- Chapter 9 discusses first how the system boots itself and then describes how you can alter this “standard” configuration.
- Chapter 10 describes using “non-disc” mass storage devices: EPROM and Magnetic Bubble Memory cards, and cartridge tape drives.
- Appendices discuss these topics: System History, file interchange between Series 200 language systems, physical and software memory maps, command summaries, glossary, error messages, and subject index.

Pascal 3.0 Procedure Library

This manual describes the procedures and functions provided with the Workstation System. It begins with an overview of modules and the mechanics of using them. The I/O Procedure Library is then covered in detail using a task-oriented approach. Several general and specific examples are provided. The last section of the book provides an object-oriented discussion of each procedure and function in the Procedure Library.

- Chapter 1 provides an overview of using the procedures and functions provided in the Procedure Library. You **must** read this chapter (or be familiar with the concepts) if you want to painlessly use the rest of the manual.
- Chapters 2 through 9 describe general I/O programming techniques.
- Chapters 10 through 13 describe specific techniques for using the HP-IB, Datacomm, Serial, and GPIO interfaces.
- Chapter 14 is an *advanced* programmer’s tutorial on using the “system devices” such as the beeper, softkeys, clock, timers, and other built-in hardware features.
- Chapter 15 is also an *advanced* programmer’s tutorial on how to segment large programs into smaller ones at run time (to decrease memory requirements).
- The Procedure Library Reference section describes individual procedures and functions provided by the Procedure Library.
- There is also a glossary and subject index at the end of the manual.

Pascal 3.0 Graphics Techniques

This manual describes graphics concepts and then graphics programming techniques. It is mostly a task-oriented manual, although it does contain an object-oriented Graphics Procedures Reference appendix which describes the procedures and functions provided by the GRAPHICS modules.

- This manual begins in Chapter 1 by describing some fundamental graphics concepts and programming techniques.
- Chapter 2 continues with additional concepts and techniques.
- Chapter 3 describes color graphics and interactive graphics programming techniques.
- Appendix A provides several program listings.
- Appendix B provides descriptions of GRAPHICS procedures and functions provided in the Procedure Library (these descriptions are *exact* copies of descriptions found in the Reference section of the *Pascal Procedure Library* manual).
- This manual also has a subject index.

HP Pascal Language Reference for Series 200 Computers

This manual describes Pascal reserved words, standard identifiers, procedures, and functions, and terms relevant to the Pascal programming language. It is entirely an object-oriented manual.

- The Keyword Dictionary section describes these topics: manual organization; symbols, identifiers, reserved words, operators, statements, procedures, and other features of the HP Standard Pascal language.
- The HP-UX Implementation section describes the specific features of the Series 200 HP-UX Pascal Compiler (which is irrelevant *unless* you also have a Series 200 HP-UX system).
- The Workstation Implementation section describes these specific features of the Series 200 Pascal Workstation System: Compiler options, implementation restrictions, UCSD Pascal extensions, Series 200 system programming extensions, Series 200 Pascal Workstation File System, heap management, and error messages.

MC68000 User's Manual

This manual describes the hardware operation, Assembler language, and machine language of the Motorola MC68000 family of microprocessors. You will only need to read it if you are going to be programming in Assembler language. It is mostly an object-oriented manual.

- Section 1 describes the hardware architecture of the MC68000 family of processors. (Note that only 68000 and 68012 processors, not 68008 or 68010 processors, are used in Series 200 machines.)
- Section 2 describes addressing modes and data organization.
- Section 3 details the instruction set.
- Section 4 describes how “exceptions” are processed.
- Appendix A discusses condition codes in detail.
- Appendix B provides an alphabetical reference of the Assembler language instructions, and Appendix C summarizes the format of these instructions.
- Appendices D, E, and F show how to determine the time required to execute instructions for different processors in the MC68000 family.
- Appendix G discusses the looping instructions available with the MC 68010 processor.

The Master Index

The Master Index is a merger of the indexes in the individual manuals in this set. This section describes the notation used in the index.

Referencing Scheme

Since the Master Index references more than one book, it must indicate which book the referenced subject exists in. Here is the notation used to specify where the subject is covered.

UG: *Pascal 3.0 User's Guide*
 WS: *Pascal 3.0 Workstation System*
 PL: *Pascal 3.0 Procedure Library*
 GT: *Pascal 3.0 Graphics Techniques*

Note that the following manuals are **not** referenced in the Master Index:

- *Programming and Problem Solving with Pascal*
- *HP Pascal Language Reference for HP Series 200 Computers*
- *MC68000 User's Manual*

The Pascal programming text has its own index. The language reference does not need an index, since topics are listed in alphabetical order. The 68000 manual has no index.

Here is a sample of index entries:

Autostart files:

Booting with	UG: 182
	WS: 392
Changing	UG: 204
Confirming	UG: 183
Creating	UG: 178, 238
	WS: 420
Description of	UG: 177
	WS: 392
Modifying for Winchester disc	UG: 180
Storing	UG: 181

Note the following characteristics of this notation:

- The acronym that identifies each manual (such as **UG:** or **WS:**) *always* precedes all page numbers for a given topic.
- When a topic is found in more than one manual, then each list of page numbers begins on a separate line and is preceded by the acronym.

Happy Programming!

Manual Comment Sheet Instruction

If you have any comments or questions regarding this manual, write them on the enclosed comment sheets and place them in the mail. Include page numbers with your comments wherever possible.

If there is a revision number, (found on the Printing History page), include it on the comment sheet. Also include a return address so that we can respond as soon as possible.

The sheets are designed to be folded into thirds along the dotted lines and taped closed. Do not use staples.

Thank you for your time and interest.

Subject Index

a

- | | | | |
|---|--------------------|---------------------------------|--------------|
| Abort (HP-IB) | PL: 86 | Exception coding | WS: 273 |
| Aborting prompts | UG: 46 | Expressions | WS: 276 |
| Absolute address (of variables) . . | WS: 229, 232 | EXT table | WS: 265 |
| Acceleration, pen. | GT: 86 | EXTERNAL procedures. | WS: 274 |
| Access command (Filer). | WS: 144 | IMPORT text. | WS: 264 |
| Access rights (SRM). | WS: 63, 128 | Instruction format | WS: 275 |
| ACCESS volume | UG: 268 | Introduction. | WS: 259 |
| Active controller (HP-IB). | PL: 78, 83 | Invoking. | WS: 260 |
| Address (HP-IB). | PL: 83 | Listing | WS: 260, 262 |
| Addressed to listen state (HP-IB) | PL: 89 | Local variables | WS: 268 |
| Addressed to talk state (HP-IB). | PL: 89 | Module initialization | WS: 271 |
| Addresses (HP-IB) | PL: 78 | Modules. | WS: 263 |
| Addresses (of I/O). | WS: 522 | Object file | WS: 261 |
| Addresses (of RAM). | WS: 520 | Opcode size suffix. | WS: 275 |
| Addresses (of ROM). | WS: 520 | Opcodes | WS: 275 |
| Addresses (used by system). | WS: 525 | Passing Parameters. | WS: 266 |
| Addressing range | WS: 520 | Pseudo ops | WS: 280 |
| Adjust command (Editor). | WS: 92 | Source file | WS: 260 |
| Advanced bus management (HP-IB) . . . | PL: 94 | Symbols. | WS: 275 |
| ALIAS (Compiler option). | WS: 198 | Use of the stack | WS: 273 |
| ALLOCATE module | PL: 17 | Assembler pseudo ops: | |
| ALPHA key. | UG: 75, 90 | COM | WS: 280 |
| Alphabetical directory listing | UG: 147 | DC | WS: 281 |
| Alternate DAMs | WS: 405 | DECIMAL | WS: 281 |
| Anisotropic scaling. | GT: 10 | DEF | WS: 282 |
| ANSI (Compiler option). | WS: 199 | DS | WS: 282 |
| ANY C key | UG: 103 | END. | WS: 283 |
| ANY CHAR key | UG: 90 | EQU. | WS: 283 |
| ANYCHAR key | UG: 74 | INCLUDE | WS: 283 |
| ANYPTR data type. | WS: 232 | LIST. | WS: 284 |
| APPEND (file) | WS: 50, 51, 60 | LLEN. | WS: 284 |
| Arrow keys | UG: 83, 97, 109 | LMODE. | WS: 285 |
| ASM volume. | UG: 268 | LPRINT. | WS: 285 |
| Aspect ratio. | GT: 11, 34, 60, 98 | MNAME. | WS: 286 |
| Assembler subsystem | UG: 163, 212, 267 | NOLIST. | WS: 286 |
| Assembler: | | NOOBJ | WS: 287 |
| Addressing modes. | WS: 276-9 | NOSYMS | WS: 287 |
| Declaring global variables | WS: 319 | ORG | WS: 288 |
| Declaring module name. | WS: 266 | PAGE. | WS: 288 |
| DEF table | WS: 264 | REFA. | WS: 289 |
| Error recovery. | WS: 271 | REFR. | WS: 289 |
| Errors. | WS: 560 | RMODE. | WS: 290 |
| Example modules. | WS: 293 | RORG | WS: 290 |

Serial transfers	PL: 72
Special transfers	PL: 76
Terminating transfers	PL: 74
Word transfers	PL: 76
Writing data to	PL: 71
BUF_INFO_TYPE	PL: 69
Bus	PL: 22
Bus address	PL: 44
Bus line states (HP-IB)	PL: 92
Bus sequences (HP-IB)	PL: 81
Byte	PL: 27

C

C I/O key	UG: 108
Cable options (Datacomm)	PL: 143
Cable options (Serial)	PL: 177
CALL command (Debugger)	WS: 233
CALLABS (Compiler option)	WS: 200
CAPS key	UG: 110
Caps key	UG: 84
CAPS LOCK key	UG: 98
CARD_ID	PL: 39-41
CARD_TYPE	PL: 39-41
Cartesian coordinates	GT: 6
Cartridge tape drives	WS: 465
CASE statement	WS: 244
CASE statements	WS: 255
Cell, character	GT: 43
Centering labels	GT: 17
Change command (Filer)	UG: 148, 251
	WS: 137, 147, 147
Changing memory contents	WS: 352
Chapter previews	WS: 2, 3
	PL: 2
Character cell	GT: 43
Character format (Datacomm)	PL: 133
Character format (Serial)	PL: 156, 158, 161
Character length (Datacomm)	PL: 123
Character sets	UG: 85
	WS: 527
Character size, setting	GT: 16, 45
Characters (internal representation of) ..	PL: 29
CharCell program	GT: 43, 157
CHARSIZE procedure	GT: 46, 50
Choosing the graphics display device ...	GT: 6
Clear (HP-IB)	PL: 86
Clear line key	UG: 87
Clearing workfiles	UG: 245
CLEAR_DISPLAY procedure	GT: 55, 225
CLIPDRAW procedure	GT: 25, 32, 62
Clipping lines	GT: 23
Clock (System devices)	PL: 219
Clock, setting the	UG: 25, 210
CLOSE (file)	WS: 51
Closed loop system	GT: 87
CLR I/O key	UG: 96
CLR L key	UG: 111
CLR LN key	UG: 100
CMP volume	UG: 268
Coalescing hard-disc volumes	WS: 388, 396, 397, 409
CODE (Compiler option)	WS: 201
CODE files	UG: 115, 159
CODE_OFFSETS (Compiler option)	WS: 202
Colon (default volume)	UG: 118
Color displays, external	GT: 84
COLOR program	GT: 107, 158
Color:	
Additional colors	GT: 116, 121, 123
Business	GT: 100
CMY Color Cube	GT: 111
Dithered colors	GT: 118, 121
Effective use of	GT: 133
Gamuts	GT: 137
Graphics	GT: 99
Hardcopy	GT: 137
HSL Color Cylinder	GT: 112
HSL model	GT: 103, 107
Hue	GT: 103
Luminosity	GT: 103
Map	GT: 122
Mixing	GT: 134
Model resolution	GT: 126
Models	GT: 102, 107
Objective use of	GT: 135
Primary	GT: 100
References	GT: 139
RGB Color Cube	GT: 110
RGB model	GT: 102, 107
Saturation	GT: 103
Seeing	GT: 133
Spaces	GT: 109
Subjective use of	GT: 135
Table	GT: 100
Vector	GT: 118
Command Interpreter file (STARTUP)	WS: 391
Command lines	UG: 42, 64

UG: *Pascal 3.0 User's Guide*

WS: *Pascal 3.0 Workstation System*

PL: *Pascal 3.0 Procedure Library*

GT: *Pascal 3.0 Graphics Techniques*

- Command reference:
- Debugger WS: 363
 - Editor WS: 90
 - Filer WS: 140
 - Librarian WS: 323-5
- Command summary:
- Debugger WS: 361, 541
 - Editor WS: 90, 538
 - Filer WS: 140, 539
 - Librarian WS: 361, 540
 - Main Command Level WS: 5, 537
- Commands:
- Access (Filer) WS: 144
 - Adjust (Editor) WS: 92
 - Bad sector (Filer) WS: 146
 - Change (Filer) WS: 147
 - Copy (Editor) WS: 94
 - Debugger (summary) WS: 365
 - Delete (Editor) WS: 96
 - Duplicate (Filer) WS: 149
 - Equals (=) (Editor) WS: 98
 - Exchange (Editor) WS: 118
 - Exiting UG: 216
 - eXecute (Main level) WS: 7
 - Extended directory (Filer) WS: 150
 - Filecopy (Filer) WS: 153
 - Find (Editor) WS: 99
 - Get (Filer) WS: 156
 - Initialize (Main Level) WS: 8
 - Insert (Editor) WS: 102
 - Invoking UG: 215
 - Jump (Editor) WS: 105
 - Krunch (Filer) WS: 157
 - Librarian (Summary) WS: 323
 - List directory (Filer) WS: 159
 - Main Level WS: 4, 5
 - Make (Filer) WS: 161
 - Margin (Editor) WS: 106
 - Memory volume (Main Level) WS: 9
 - New (Filer) WS: 163
 - New sysvol (Main Level) WS: 11
 - Page (Editor) WS: 107
 - Permanent (Main Level) WS: 12
 - Prefix (Filer) WS: 164
 - Quit (Editor) WS: 108
 - Quit (Filer) WS: 166
 - Remove (Filer) WS: 167
 - Replace (Editor) WS: 110
 - Run (Main Level) WS: 13
 - Save (Filer) WS: 169
 - Set (Editor) WS: 113
 - Stream (Main Level) WS: 14
 - Syntax diagram WS: 6
 - Translate (Filer) WS: 171
 - Unit directory (Filer) WS: 172
 - User restart (Main Level) WS: 17
 - Version (Main Level) WS: 18
 - Volumes (Filer) WS: 174
 - What (Filer) WS: 175
 - What (Main Level) WS: 20
 - Zap (Editor) WS: 120
 - Zero (Filer) WS: 176
 - Commands table (HP-IB) PL: 96
 - Compacting volume space UG: 150, 255
 - Compatibility (of interfaces) PL: 24
 - Compatibility (UCSD and HP Pascal) WS: 245
 - Compile strategy (for modules) PL: 6
 - Compiler:
 - Absolute address (of variables) WS: 229, 232
 - ANYPTR type WS: 232
 - CALL WS: 233
 - CASE statements WS: 255
 - Compatibility rules WS: 245
 - Compiling workfiles UG: 161, 189
 - Converting UCSD Pascal Programs WS: 239
 - Data area sizes WS: 255
 - Description of UG: 114, 155
 - Entering UG: 157, 212, 256
 - Error trapping and simulation WS: 229
 - Errors WS: 195, 556
 - Exiting a procedure WS: 243
 - Function calls WS: 248
 - Function results WS: 249
 - Global variables WS: 246
 - Implementation restrictions WS: 254
 - Intrinsics PL: 13
 - INCLUDE files WS: 194
 - Introduction WS: 179
 - Invoking WS: 180
 - IOCHECK and IORESULT WS: 234
 - IORESULT function WS: 233
 - Listing WS: 182
 - Memory requirements UG: 267
 - Mixing DISPOSE and RELEASE WS: 238
 - Modules WS: 185
 - Nested comments WS: 244
 - Output (CODE) files UG: 159, 257
 - Parameter passing WS: 248
 - Printer (program) listings UG: 158, 257
 - Procedure calls WS: 247
 - Relaxed typechecking WS: 231

- Running the program. WS: 183
- SEARCH option. WS: 191
- Separate compilation units WS: 245
- Separate module compilation WS: 190
- Stack usage. WS: 246
- Static links. WS: 251
- Strategy for compiling modules. WS: 306
- UCSD options. WS: 179
- Unreported errors. WS: 258
- Useful hints (UCSD). WS: 243
- Using . . . UG: 158, 189, 192, 196, 199, 256
- Variable size WS: 230
- Workfile. WS: 183
- Compiler options:
 - ALIAS WS: 198
 - ANSI WS: 199
 - CALLABS. WS: 200
 - CODE WS: 201
 - CODE_OFFSETS. WS: 202
 - COPYRIGHT WS: 203
 - DEBUG WS: 204, 246
 - DEF WS: 205
 - FLOAT_HDW WS: 207, PL: 15
 - General WS: 197
 - HEAP_DISPOSE. WS: 206, PL: 13
 - IF WS: 208
 - INCLUDE WS: 209
 - IOCHECK. WS: 210
 - LINENUM. WS: 211
 - LINES WS: 212
 - LIST. WS: 213
 - OVFLCHECK. WS: 214
 - PAGE. WS: 215
 - PAGEWIDTH. WS: 216
 - PARTIAL_EVAL. WS: 217
 - RANGE WS: 218, PL: 39
 - REF WS: 219
 - SAVE_CONST WS: 220
 - SEARCH. WS: 221, PL: 6
 - SEARCH_SIZE. WS: 222
 - STACKCHECK WS: 223
 - STACKCHECK_ON WS: 246, 247
 - SWITCH_STRPOS WS: 224
 - SYSPROG WS: 225, 229, PL: 62
 - TABLES WS: 226
 - UCSD WS: 227
 - WARN. WS: 228
- Compiling a program. UG: 157, 256
- Compiling demonstration programs. GT: 4
- Compiling modules WS: 305
- Compiling programs. UG: 192
- Complementing lines GT: 55, 128
- Computer (block diagram) PL: 22
- Computer resource PL: 21
- CONFIG volume UG: 269
- Configuration:
 - Bubbles and EPROM. WS: 404
 - CS80 discs WS: 422
 - Example of SRM WS: 451
 - Interfaces. WS: 400
 - Modifying the standard WS: 409
 - Multi-disc SRM WS: 463
 - Printers WS: 403
 - Verifying changes to. WS: 447
- CONSOLE volume. UG: 152
- CONT key UG: 103, 74
- CONTINUE key UG: 92
- Continuous degrees of freedom. GT: 92
- Control blocks (Datacomm) PL: 120, 129, 134
- Control characters (System devices) PL: 234
- Control value (DISPLAY_INIT) GT: 7
- ControlWord variable GT: 7
- Conversion between coordinate systems GT: 40
- ConvertVirtualToWorld program. GT: 41
- ConvertWorldToVirtual program. GT: 42
- CONVERT_WTODMM procedure GT: 24, 226
- CONVERT_WTOLMM procedure GT: 227
- Coordinate systems, conversion between GT: 40
- Coordinates:
 - Cartesian. GT: 6
 - Rectangular GT: 6
 - Virtual. GT: 13
 - World GT: 13, 226, 227
- Copy command (Editor) UG: 131, WS: 94
- Copying discs UG: 248, WS: 131
- Copying files UG: 147, 202, 245, WS: 134
- Copying files (to SRM). WS: 457
- Copying Pascal system to hard disc UG: 166, 230
- Copying system files. WS: 417
- Copying volumes UG: 248, WS: 131
- COPYRIGHT (Compiler option) WS: 203

UG: *Pascal 3.0 User's Guide*

WS: *Pascal 3.0 Workstation System*

PL: *Pascal 3.0 Procedure Library*

GT: *Pascal 3.0 Graphics Techniques*

Cpy command (Editor)	UG: 131
	WS: 94
Creating a file	UG: 125, 239
Creating an SRM Directory	WS: 133
CRT drawing modes	GT: 55, 128
CRT highlight characters	WS: 536
CRT information	PL: 236
CRT interface (select code 1)	PL: 43
CRT, graphics	GT: 6
CrtAddr variable	GT: 7, 81
Crunch command	UG: 150, 255
CS80 discs (configuration)	WS: 388
CsizeProg program	GT: 165
CTABLE source program:	
Commentary	WS: 430
Compiling	WS: 447
Editing	WS: 446
CTR module (CTABLE)	WS: 441
CTRL key	UG: 80, 94, 106
Cube, Color	GT: 110
Cursor	UG: 70
Cursor control (System devices)	PL: 238
Cursor wheel	WS: 72, 86
Customizing demo programs for your system	GT: 6
Cylinder, Color	GT: 112

d

DAMs (CTABLE)	WS: 432
Data compatibility	PL: 24
Data flow, directing	PL: 43
Data input:	
Datacomm	PL: 120
General	PL: 53
GPIO	PL: 199
HP-IB	PL: 79
Serial	PL: 163
Data link connections (Datacomm) ...	PL: 136
Data link options (Datacomm)	PL: 133
Data link protocol (Datacomm)	PL: 119
Data messages (Datacomm)	PL: 122
Data messages (HP-IB)	PL: 81
Data output:	
Datacomm	PL: 120
General	PL: 45
GPIO	PL: 199
HP-IB	PL: 79
Serial	PL: 162

Data representations:	
Bits and bytes	PL: 27
Characters	PL: 29
GPIO	PL: 199
Numbers	PL: 28
Real numbers	PL: 31
Signed integers	PL: 29
Data types:	
I/O	PL: 38-42
Supported for input	PL: 53
Supported for output	PL: 45
Data-driven plotting	GT: 71
Datacomm:	
Asynchronous	PL: 129
Asynchronous protocol	PL: 118
Auto-dialing	PL: 136
Auto-poll	PL: 141
Baud rate	PL: 123, 130
Block size	PL: 135
Break timing	PL: 133
Cable adapter options	PL: 143
Character format	PL: 133
Character length	PL: 123
Connecting to the line	PL: 135
Connection procedures	PL: 136
Control blocks	PL: 120, 129, 134
Data Communication Basics (98046-90005)	PL: 117
Data link connections	PL: 136
Data link options	PL: 133
Data link protocol	PL: 119
Data messages	PL: 122
DCE and DTE cable options	PL: 143
Defaults	PL: 127
Dialing procedures	PL: 136
Direct connection links	PL: 135
Driver/receiver circuits	PL: 144
End-of-line recognition	PL: 132
Errors and recovery	PL: 138
Establishing the connection	PL: 126
Example terminal emulator	PL: 124
Half-duplex	PL: 142
Handshake	PL: 131, 134
Handshake characters	PL: 132
Initiating connection	PL: 137
Introduction	PL: 117
IOSTATUS and IOCONTROL registers	PL: 145
Line timeouts	PL: 130
Non-data characters	PL: 132
Operating parameters	PL: 126

Overview of programming	PL: 123	Loading	WS: 333, 335
Parity	PL: 118, 123, 135	Pause function	WS: 346
Preventing data loss	PL: 140	Prompt	WS: 338
Private links	PL: 135	Queue	WS: 340
Programming helps	PL: 140	Sample session	WS: 334
Prompt recognition	PL: 132	Screen dumps	WS: 340
Protocol	PL: 118, 128	Single-stepping	WS: 339
Reset	PL: 128	Slow program execution	WS: 339
RS-232C cable signals	PL: 143	Stack frame	WS: 348
Secondary channel	PL: 142	Static and dynamic links	WS: 353
Start bit	PL: 118	Tracing program flow	WS: 347
Stop bits	PL: 118, 123	Windows (System devices)	PL: 245
Telephone links	PL: 135	Debugger commands:	
Terminal identification	PL: 134	B.	WS: 365
Terminal prompt messages	PL: 140	BA	WS: 365
Datapoint function	GT: 6	BC	WS: 366
DataPoint program	GT: 166	BD	WS: 366
Date and time (System devices)	PL: 219	BS	WS: 367
Date, setting system	UG: 24, 210	CALL	WS: 368
DC600 tape drives	WS: 465, 497	D	WS: 369
DCE and DTE cables (Datacomm)	PL: 143	DA	WS: 371
DCE cable (Serial)	PL: 178	DG	WS: 371
DEBUG ON (Compiler option)		EC	WS: 372
WS: 204, 246, 334		ET	WS: 372
Debugger:		ETC	WS: 373
Breakpoint Table	WS: 345	ETN	WS: 373
Breakpoints	WS: 343	FB	WS: 374
Changing memory contents	WS: 352	FH	WS: 374
Clearing Breakpoints	WS: 346	FI	WS: 374
Code file specification	WS: 337	FO	WS: 374
Command reference	WS: 363	FU	WS: 374
Command screen	WS: 338	G	WS: 375
Command summary	WS: 361, 541	GF	WS: 375
DEBUG Compiler option	WS: 334	GT	WS: 376
Default display formats	WS: 343	GTF	WS: 376
Display formats	WS: 341	IF, ELSE, END	WS: 377
Displaying data	WS: 340	OL,OW,OB.	WS: 379
Errors	WS: 561	PN	WS: 380
Examining consecutive memory	WS: 350	PX	WS: 380
Examining variables	WS: 348	Q	WS: 381
Example program	WS: 334	QE	WS: 381
Exception trapping	WS: 354	QS	WS: 381
Executing a number of statements	WS: 346	Register operations	WS: 383
Expressions	WS: 363	sb	WS: 383
Formats for structured variables	WS: 351	SF	WS: 348
General	UG: 164	Softkey commands	WS: 382
Generating Escapes	WS: 355	T	WS: 384
Input formats	WS: 343	TD	WS: 384
Introduction	WS: 333	TQ	WS: 384
Invoking	WS: 337	TT	WS: 385
Is it installed?	WS: 337, 357	WD	WS: 386
Key notation	WS: 336	WR	WS: 386
Keyboard	WS: 357	WS	WS: 386

- Declared record length. WS: 256
- DEF (Compiler option) WS: 205
- DEF table WS: 264, 326
- DEF table command (Librarian) WS: 317
- Default volume UG: 117, 151, 176, 236
WS: 21, 28, 124
- Defaults:
 - Datacomm switches PL: 127
 - Device address vectors (CTABLE) WS: 434
 - Display formats (Debugger) WS: 343
 - GPIO switches PL: 187-8
 - HP-IB switches PL: 78
 - PRINTER volume WS: 393, 403, 443
 - Serial switches PL: 157-8
 - Values (in prompts) UG: 46, 219
- Define Source WS: 326
- Defining a viewport GT: 13
- Degrees of freedom:
 - Continuous GT: 92
 - Non-separable GT: 92
 - Number of GT: 88
 - Quality of GT: 88
 - Quantizable GT: 93
 - Separability of GT: 88, 92
- DEL C key UG: 111
- DEL CHR key UG: 100
- DEL key UG: 87
- DEL L key UG: 111
- DEL LN key UG: 100
- Delete char key UG: 87
- Delete command (Editor) UG: 128
WS: 96
- Delete line key UG: 87
- Deleting a file UG: 149, 249
WS: 138
- Demonstration programs GT: 4, 6
- Dependency of modules (table) PL: 20
- Destination (of I/O operations) PL: 22
- Device classes (TABLE program) WS: 394
- Device driver modules WS: 390, 400, 421
- Device priority (while booting) WS: 395
- Device selectors:
 - DISPLAY_INIT GT: 6
 - General PL: 38, 43, 44
 - HP-IB PL: 79
 - PRINTER WS: 403
- Device-independent Graphics
 - Language (DGL) PL: 16
 - DGLPRG disc GT: 1
 - Dialing procedures (Datacomm) PL: 136
 - Direct access files WS: 54
 - Direct connection links (Datacomm) . . PL: 135
 - Directing data flow PL: 43
 - Direction of labels, setting GT: 17
 - Direction, label GT: 48
 - Directory access methods (DAMs)
 - WS: 9, 36, 405
 - Directory path syntax WS: 32
 - Directory:
 - Description of UG: 38
 - Listing alphabetically UG: 144
 - Listing files in UG: 142, 144, 253
 - Disassembly of a module WS: 295
 - Discs:
 - General WS: 24, 26
 - Interleave WS: 24
 - Performance WS: 402
 - Unit number assignments UG: 47, 225, 226
 - Write-protection UG: 52
 - System WS: 389
 - Disc, flexible:
 - Formatting UG: 26, 220
 - Handling UG: 10
 - Initialization UG: 26, 220
 - Insertion UG: 12
 - Removing UG: 13
 - Disc, Winchester (hard):
 - Formatting UG: 30, 222
 - Initialization UG: 30, 222
 - Autostart file UG: 180
 - Booting from UG: 170
 - Copying Pascal system UG: 166, 230
 - Displays:
 - Control characters (System devices) PL: 234
 - Debugger WS: 340
 - Designing GT: 134
 - External color GT: 84
 - Formats (Debugger) WS: 341
 - Limits, setting GT: 33
 - Organization of UG: 64
 - Turning on and off GT: 39
 - DISPLAY_FINISH procedure GT: 228
 - DISPLAY_INIT procedure GT: 6, 81, 84, 232
 - DISPLAY_TERM procedure GT: 237
 - DISPOSE WS: 236
 - DISPOSE (procedure) PL: 13
 - Dithered colors GT: 121
 - Dithering GT: 75, 117, 123
 - Dlete command UG: 128
 - DMA card (configuration) WS: 388
 - DMP A key UG: 76
 - DMP G key UG: 76
 - Document editing environment UG: 133
 - Dollar sign wildcard UG: 148, 167, 202, 245

Dominant lines, drawing GT: 55, 128
 Drawing lines GT: 7
 Drawing modes, CRT GT: 55, 128
 DrawMdPrg program GT: 56, 166
 Drive numbers WS: 27
 Driver/receiver circuits (Datacomm) . . . PL: 144
 DTE cable (Serial) PL: 177
 DUMP ALPHA key UG: 91
 DUMP GRAPHICS key UG: 91
 Dumping raster images GT: 82
 Duplicate command (Filer) WS: 149

e

Echoes:

Built-in GT: 94
 General GT: 221
 Rubber GT: 97
 EDIT key UG: 90

Editor:

Anchor WS: 86
 Backing up your file WS: 85
 Changing text WS: 75
 Command summary: Editor WS: 538
 Confirming or aborting commands . . . WS: 71
 Copying text from other files WS: 70
 Cpy command UG: 131
 Creating a text file WS: 67
 Creating text WS: 67, 68
 Cursor WS: 86
 Deleting text WS: 73
 Description of UG: 114, 125
 Dlete command UG: 128
 Duplicating text WS: 74
 Editing characteristics UG: 133
 Entering UG: 61, 125, 212
 Entering the WS: 66
 Exiting UG: 62, 136
 Exiting the Editor WS: 84
 File size WS: 87
 Finding text patterns WS: 80
 Formatting text WS: 80
 I/O errors WS: 89
 Insrt command UG: 126
 Introduction WS: 65
 Margin command UG: 135
 Margining text WS: 82
 Memory requirements UG: 267
 Moving text WS: 74
 Moving the cursor WS: 72

Quitting UG: 62
 Recovering deleted text WS: 74
 Set environment command UG: 133
 Setting the environment WS: 82, 83
 Storing an edited file UG: 136, 187
 Storing your file WS: 69, 84
 Stream Files WS: 89
 Text files WS: 88
 Using workfiles WS: 88
 Window WS: 86
 Xchg command UG: 129
 Electrical compatibility PL: 24
 END condition transfers PL: 76
 End or Identify (HP-IB) PL: 91
 End-of-line recognition (Datacomm) . . PL: 132
 Enter key UG: 79
 ENTER key UG: 92, 104
 Environment, programming UG: 165
 Environments, editing UG: 133
 EPROM cards:

As the System Volume WS: 482
 Blank check WS: 488
 Burn failure WS: 491
 Burn rate WS: 487
 Check failure WS: 490
 Configuration changes WS: 404, 476
 Configuration modifications WS: 494
 Driver module WS: 491
 Driver modules WS: 477
 Empty sockets WS: 487
 File system access WS: 496
 General UG: 47
 Headers WS: 483
 Memory addresses WS: 481
 Memory card installation WS: 479
 Overview of using WS: 404, 465, 476
 Programmer card installation WS: 477
 Programmer card select code WS: 478
 Programmer select code WS: 486
 Programming utility WS: 482
 Transfer utility WS: 485
 Transferring files WS: 483
 Transferring volumes WS: 482, 489
 Equal sign wildcard UG: 167, 247
 Equals (=) command (Editor) WS: 98
 Erasing lines GT: 55, 128
 Errors:

Assembler WS: 560
 Boot-time WS: 550
 Booting UG: 20
 Compiler WS: 195, 556
 Datacomm PL: 138

Duplicate_link	WS: 458	Declaring a TEXT file	WS: 56
Entering	UG: 63, 139, 212	Deleting	WS: 138
	WS: 122	Disposing of	WS: 51
Exiting	UG: 63, 154	File buffer	WS: 48
Extended directory command	WS: 127, 150	File modes	WS: 49
Filecopy command		File position	WS: 48
.	UG: 55, 58, 147, 167, 202, 228, 245	File specification (syntax)	WS: 142
	WS: 131, 134, 153	File variable	WS: 47
Get command	UG: 142	Formatted I/O	WS: 58
	WS: 156	F^	WS: 48
Introduction	WS: 121	General Discussion	WS: 29
Krunch command	UG: 150, 255	GET	WS: 53
	WS: 157	Interchange between	
Ldir command	UG: 142, 144, 253	BASIC and Pascal	WS: 515
Leaving the filer	WS: 139	LIF file names	WS: 34
List directory command	WS: 126, 159	Lookahead mode	WS: 47
Make command	WS: 161	MAXPOS	WS: 56
Memory requirements	UG: 267	Names to avoid	WS: 40
New command	UG: 152	Naming Conventions	WS: 30
	WS: 163	Object (definition of)	WS: 302
Prefix command	WS: 29, 164	Object modules	WS: 185
Prefix-vol command	UG: 151, 176	OPEN	WS: 50, 60
Prompt	WS: 122	Opening existing	WS: 51
Quit command	WS: 166	Pascal operations	WS: 47
Quitting	UG: 63	POSITION	WS: 56
Remove command	UG: 149, 249	Programming with	WS: 47
	WS: 167	PUT	WS: 53
Removing files	WS: 138	READ	WS: 52
Save command	UG: 143	Read mode	WS: 47
	WS: 169	READDIR	WS: 54
SRM access rights	WS: 128	Removing	WS: 138
Translate command	UG: 153, 260	Renaming	WS: 137
	WS: 38, 129, 170	RESET	WS: 60
Unit directory command	WS: 172	REWRITE	WS: 50, 51, 60
Vols (Volumes) command		SEEK	WS: 55
.	UG: 48, 50, 59, 152, 255	Sequential operations	WS: 52
	WS: 26, 174	Size specification	WS: 35, 48
Volume back-up	WS: 131	Specification	UG: 44, 224
What command	WS: 175		WS: 31
What devices are accessible?	WS: 123	SRM concurrent file access	WS: 61
Wildcards	WS: 129	SRM names	WS: 35
Workfile	WS: 139	Stream	WS: 14, 69
Zero command	UG: 35	Structure of text files	WS: 88
	WS: 176	Suffixes	WS: 36
Files:		Suppressing the suffix	WS: 37
APPEND	WS: 49, 60	Syntax of name	WS: 33
Buffer variable	WS: 49	Systm	WS: 389, 399
Creating a text file	WS: 67	Temporary	WS: 48
Creating new files	WS: 47	Textfile I/O	WS: 56
Current component	WS: 48	Translating between Data Types	WS: 38
Debugging	WS: 60	Types	WS: 33, 36, 52

UG: *Pascal 3.0 User's Guide*WS: *Pascal 3.0 Workstation System*PL: *Pascal 3.0 Procedure Library*GT: *Pascal 3.0 Graphics Techniques*

- IOCONTROL and IOSTATUS registers
PL: 99
- IOREAD_BYTE and IOWRITE_BYTE registers
PL: 103
- Listen and talk messages
PL: 81
- Local lockout
PL: 85
- Local lockout state
PL: 89
- Messages
PL: 94
- Multiple listeners
PL: 82
- Non-active controller
PL: 82
- Pass control
PL: 87
- Polling
PL: 87
- Remote enable
PL: 91
- Remote message
PL: 84
- Remote state
PL: 89
- Secondary addresses
PL: 84
- Send command
PL: 98
- Service request
PL: 92
- Service requested state
PL: 89
- Status
PL: 83
- Summary of bus sequences
PL: 113
- System controller
PL: 80, 83
- System controller jumper/switch
PL: 78
- Triggering
PL: 86
- Unlisten and untalk messages
PL: 83
- HPIB modules
PL: 34, 37
- HPM module
PL: 13
- HSL color model
GT: 103, 107, 126
- Hue
GT: 103
- i**
- I/O (definition of)
PL: 22
- I/O addresses
WS: 522
- I/O error handling
PL: 63
- I/O errors
PL: 61
- I/O events (errors and timeouts)
PL: 61
- I/O library errors
WS: 553
- I/O memory map
WS: 522
- I/O Procedure Library:
- GENERAL modules
PL: 34, 36
 - HPIB modules
PL: 34, 37
 - Initialization
PL: 35
 - Introduction
PL: 33
 - IODECLARATIONS module
PL: 38
 - Organization
PL: 34
 - SERIAL modules
PL: 35, 38
- I/O system errors
WS: 552
- I/O terminology
PL: 21
- I/O timeouts
PL: 61, 65
- Identifying flexible disc drives
UG: 47
- Identifying Winchester (hard) discs
UG: 50
- IF (Compiler option)
WS: 208
- Images, dumping
GT: 82
- Images, storing and retrieving
GT: 68
- IMPLEMENT
WS: 329
- Implementation restrictions
WS: 254
- IMPORT statement
WS: 329
- IMPORT text
WS: 264
- IMPORT text command (Librarian)
WS: 317
- INCLUDE (Compiler option)
WS: 194, 209
GT: 5, 7
- Indicator:
- status
UG: 65
- Initialization (I/O)
PL: 35
- Initialize command (Main Level)
WS: 8
- Initializing:
- Winchester (hard) discs
UG: 30, 222
 - Flexible discs
UG: 26, 220
WS: 25, 411
 - General
WS: 25, 411
 - Modules
WS: 271
- Initiating connection:
- Datcomm
PL: 137
 - Serial
PL: 160
- INITLIB file:
- Adding modules for SRM
WS: 460
 - Adding modules to
WS: 421
 - Description of
WS: 390
 - Module descriptions
WS: 421
 - Renaming
WS: 418
 - Required order of modules
WS: 421
- INITLIB modules
PL: 7
- Input:
- Characters
PL: 56
 - Defined
PL: 22
 - Device selection
GT: 89
 - Formats (Debugger)
WS: 343
 - Formatted
PL: 58
 - Free-field
PL: 54-57
 - Real numbers
PL: 54
 - Skipping data
PL: 57
 - Strings
PL: 55
 - Termination
PL: 54
 - Words
PL: 56
- INPUT_ESC procedure
GT: 244
- INQ_COLOR_TABLE procedure
GT: 247
- INQ_PGN_TABLE procedure
GT: 249
- INQ_WS procedure
GT: 13, 34, 37, 51, 251
- INS C key
UG: 111
- INS CHR key
UG: 100

INS L key UG: 111
 INS LN key UG: 100
 Insert char key UG: 87
 Insert command (Editor) . . . UG: 126, WS: 102
 Insert line key UG: 87
 Inserting flexible discs UG: 12
 Insrt command UG: 126
 Integer number range WS: 256
 Integers (internal representation of) . . . PL: 29
 Interactive graphics GT: 87
 Interchange of files WS: 515
 Interface clear (HP-IB) PL: 91
 Interface conditions (HP-IB) . . . PL: 89
 Interface drivers WS: 400
 INTERFACE modules PL: 14
 Interface reset:
 Datacomm PL: 128
 GPIO PL: 198
 HP-IB PL: 99
 Serial PL: 160
 Interface text WS: 263, 264
 PL: 6, 14
 Interfaces:
 Additional functions PL: 24
 Datacomm PL: 117
 Functional diagram PL: 23
 GPIO PL: 26
 HP-IB PL: 25, 77
 Overview PL: 25
 Registers PL: 59
 Select codes PL: 38, 43
 Serial PL: 26
 Why needed? PL: 23
 Interfacing concepts PL: 21
 Interleave factor UG: 29, 33, 221, 223
 Interleave, of discs WS: 24
 Interrupt priority (GPIO) PL: 187
 Interrupt overview (System devices) . . PL: 213
 INT_LINE procedure GT: 56, 258
 INT_MOVE procedure GT: 56, 260
 INT_POLYGON procedure GT: 262
 INT_POLYGON_DD procedure GT: 265
 INT_POLYLINE procedure GT: 269
 Invoking commands UG: 215
 IO data types PL: 38-42
 IO modules PL: 14
 IOCHECK (Compiler option) WS: 210
 IODECLARATIONS modules PL: 38
 IOERROR_MESSAGE PL: 64
 IOESCAPECODE PL: 63
 IOE_ISC PL: 64

IOE_RESULT PL: 63
 IOREAD_BYTE and IOWRITE_BYTE registers:
 General PL: 59
 GPIO PL: 205
 HP-IB PL: 103
 Serial PL: 168, 173
 IORESULT function WS: 233
 IOSTATUS and IOCONTROL registers:
 Datacomm PL: 145
 General PL: 59
 GPIO PL: 204
 HP-IB PL: 99
 Serial PL: 169
 ISC_TABLE PL: 39
 IsoProg program GT: 60, 180
 isotropic scaling GT: 10
 Isotropic scaling GT: 59

j

JSR instruction (68000) WS: 247
 Jump command (Editor) WS: 105
 Justifying labels GT: 50
 JustProg program GT: 53, 186

k

Katakana display characters WS: 534-5
 Kernel (operating system) WS: 390
 Key buffer (System devices) PL: 256
 Key codes (System devices) PL: 267
 Key correspondence table UG: 2, 6
 Key labels UG: 72
 Key notations WS: 1, 336
 Keyboard (System devices) PL: 250
 KEYBOARD file GT: 89
 Keyboard interface (select code 2) . . . PL: 43
 Keyboard notation (Debugger) WS: 357
 Keyboards:
 HP 46020A UG: 3, 68
 HP 98203A UG: 3, 69, 102
 HP 98203B UG: 2, 69, 89
 Model 226/236 UG: 2, 69, 89
 Keypad, numeric UG: 86, 99
 Knob UG: 97, 109
 WS: 72, 86
 PL: 264
 Krunch command (Filer) UG: 150, 255
 WS: 157

1

Label direction, setting	GT: 48
LABELJUSTIFY procedure	GT: 25
Labelling a plot	GT: 43
Labelling axes	GT: 25
Labels, justifying	GT: 50
Labels:	
Bold	GT: 19
Centering	GT: 17
Direction of.	GT: 17
Language extensions:	
System programming	WS: 229
UCSD	WS: 239
Ldir command	UG: 142, 144, 253
LdirProg program	GT: 49, 190
LEM programs	GT: 73, 76
Length of declared records	WS: 256
Length of strings	WS: 256
LIB volume	UG: 268
LIBRARIAN file	WS: 329
Librarian:	
Adding modules to System Library	WS: 310
Command summary	WS: 540
Creating a Boot file	WS: 383
Creating libraries	WS: 310
DEF table	WS: 326
DEF table command	WS: 317
Define Source	WS: 326
Detailed file information	WS: 316
EXPORT	WS: 328
EXT table	WS: 327
EXT table command	WS: 317
Flags	WS: 328
General	UG: 164, 212, 267 WS: 301
General Value or Address Record (GVR)	WS: 329
Glossary	WS: 326
IMPLEMENT	WS: 329
IMPORT	WS: 329
IMPORT text command	WS: 317
Introduction	WS: 301
Invoking	WS: 308
Libraries	WS: 302
Linking object files together	WS: 313
Main prompt	PL: 9
Mass storage requirements	WS: 425
Mass storage setup	WS: 309
Object file	WS: 330
Object module	WS: 330
Purpose of	PL: 3

REF tables	WS: 331
Reference Pointer	WS: 331
Text Record	WS: 332
Unassemble commands	WS: 318-21
Using	PL: 9
What it does	WS: 302
LIBRARY	WS: 307, 330 PL: 6, 9
LIBRARY modules	PL: 12
Library:	
Definition of	WS: 302, 330
Overview	WS: 370 PL: 3
System Library	WS: 7, 11, 12, 21, 307, 332 PL: 6 GT: 4
LIF file names	WS: 34
Limits, display	GT: 33
Line drawing	GT: 7
LINE procedure	GT: 8, 32
Line styles, selecting	GT: 57
Line timeouts (Datacomm)	PL: 130
Line value	GT: 121
LINENUM (Compiler option)	WS: 211
LINES (Compiler option)	WS: 212
Lines, clipping	GT: 23
LINK instruction (68000)	WS: 247, 269
Linking object files	WS: 313
LIST (Compiler option)	WS: 213
List directory command (Filer)	WS: 126, 159
Listen addresses (HP-IB)	PL: 81, 82
Listing a directory	UG: 142, 144, 253
Listing files on PRINTER	WS: 130
Listing files on screen	WS: 130
Loader/SEGMENTER errors	WS: 555
Loading a system	WS: 389
Loading subsystems	UG: 212
Loading the Pascal system	UG: 15 GT: 7
Local lockout (HP-IB)	PL: 85
Local lockout state (HP-IB)	PL: 89
Local printer timeouts (CTABLE)	WS: 433
Local printers (CTABLE)	WS: 432
Local variables	WS: 268
LOCATOR program	GT: 94, 98, 191
Locators	GT: 220
LOCATOR_INIT procedure	GT: 271
LOCATOR_TERM procedure	GT: 274
LOCKABLE files	WS: 61
LOCKMODULE	PL: 13
Logarithmic plotting	GT: 64

Logic sense (GPIO)	PL: 187
Logical units	WS: 27, 393
Logical volumes (hard discs) . . .	WS: 395, 396
LogPlot program	GT: 66, 194
Loopback (Serial)	PL: 167
LT instruction	GT: 57
Luminosity	GT: 103

m

Main Command Level:	
Command summary	WS: 537
Compiler command	UG: 114
Description of	UG: 113
	WS: 4, 391
Editor command	UG: 114
eXecute command	UG: 27, 31, 43, 114, 258
	WS: 7
Filer command	UG: 114
Memvol command	UG: 122, 173, 190, 233
	WS: 9
Newsysvol command	
.	UG: 118, 123, 141, 191
	WS: 11
Permanent command . . .	UG: 120, 171, 232
	WS: 12
Run command	UG: 119, 197, 200, 259
	WS: 13
User restart command. . .	UG: 30, 119, 259
	WS: 17
Version command.	UG: 121
	WS: 18
What command.	UG: 116, 174, 234
	WS: 20
Make command (Filer).	WS: 161
MAKE_PIC_CURRENT procedure . . .	GT: 275
Manual organization	PL: 1
Manual Overview	WS: 1, 2
Map, color	GT: 122
Margin command	UG: 135
Margin command (Editor)	WS: 106
MARK (procedure).	PL: 13
MARK and RELEASE	WS: 236
MARKER procedure.	GT: 79, 276
MarkrProg program	GT: 80, 196
Mass storage	PL: 8
Mass storage:	
Comparison	WS: 466
Configuration	WS: 402
Introduction.	WS: 23
Volumes.	WS: 26

Match character transfers.	PL: 76
MAXPOS (files).	WS: 56
MEDIAINIT program	UG: 27, 31, 220, 222
	WS: 25, 411
Memory (RAM).	WS: 23
Memory address, graphics	GT: 69
Memory characteristics.	WS: 23
Memory map (physical).	WS: 519
Memory map (RAM)	WS: 520
Memory map (ROM)	WS: 521
Memory map (software).	WS: 525
Memory requirements, subsystem	UG: 267
Memory size, graphics.	GT: 69
Memory volume command (Main Level)	WS: 9
Memory volumes	WS: 426
	UG: 122, 173, 190, 233
Memory, Bubble.	WS: 404
Memory, EPROM.	WS: 404
Memory-mapped I/O	WS: 522
Memvol command	UG: 122, 173, 190, 233
Menu key.	UG: 71
Menus (System devices)	PL: 242
Messages (HP-IB).	PL: 94
Micro disc:	
Formatting	UG: 26
Initialization	UG: 26
Insertion.	UG: 12
Removing	UG: 13
Write-protection	UG: 52
Mini disc:	
Formatting	UG: 26
Initialization	UG: 26
Insertion.	UG: 13
Removing	UG: 14
Write-protection	UG: 53
Mixing DISPOSE and RELEASE	WS: 238
Models 216 and 217 differences (Serial)	PL: 184
Models, color	GT: 102, 107
Modem handshake (Serial).	PL: 161
Modem line control (Serial).	PL: 166
Modem status and control (Serial)	PL: 157
Modem-line handshakes (Serial)	PL: 166
Modes, drawing	GT: 55
Module Dependency Table	PL: 20, 525
	GT: 339
Module names used by system.	WS: 254, 517
Modules:	
Adding to the System Library	PL: 9
ALLOCATE	PL: 17
Assembler	WS: 263
Comparison to UCSD units.	WS: 245
Compiling	PL: 6

Dependency table PL: 20
 Developing and testing WS: 188
 Device drivers WS: 390
 Directory PL: 3
 Examples WS: 187-8, 192, 293-300, 303-4
 Examples (on DOC disc) PL: 3
 FGRAPHICS PL: 15
 File sizes PL: 8
 GENERAL PL: 34, 36
 GRAPHICS PL: 15
 How the Compiler finds them WS: 305
 PL: 6
 How the loader finds them WS: 307
 PL: 7
 HP-IB PL: 34, 37
 HPM PL: 13
 Importing WS: 303-7
 PL: 4
 Initialization WS: 271
 INITLIB WS: 390
 INITLIB module descriptions WS: 421
 INTERFACE PL: 14
 IO PL: 14, 34
 IODECLARATIONS PL: 38
 LAST (in INITLIB) WS: 391
 LIBRARY PL: 12
 LOCKMODULE PL: 13
 Making them accessible PL: 6, 7, 18, 19
 Names used by operating system .. WS: 517
 Object (definition of) WS: 302
 Overview PL: 3
 Pascal WS: 330
 PRINTER WS: 401
 Required order in INITLIB WS: 421
 RND PL: 12
 SEGMENTER PL: 17
 Separate compilation WS: 190
 SERIAL PL: 35, 38
 Standard PL: 12
 Strategy for compiling WS: 188
 Structure of WS: 185
 SYSDEVS PL: 211
 SYSGLOBALS PL: 211
 UIO PL: 13
 Monochromatic defaults in color table GT: 101
 Mouse UG: 67.1, 78, 79, 83
 WS: 72, 86, 424
 GT: 87-98, 223, 271, 273, 293, 317
 MOVE procedure GT: 8, 32, 277
 Moving files WS: 134
 Multi-line objects GT: 72
 Multiple listeners (HP-IB) PL: 82
 Multiple on-line systems WS: 399

n

Nested comments (Compiler) WS: 244
 Nesting of INCLUDE and IMPORT .. WS: 254
 NEW (procedure) PL: 13
 New command UG: 152
 New command (Filer) WS: 163
 New sysvol Command (Main Level) ... WS: 11
 Newsysvol command UG: 118, 123, 141, 191
 No room on volume UG: 150
 Non-active controller (HP-IB) PL: 82
 Non-data characters (Datacomm) PL: 132
 Non-disc mass storage WS: 465
 Non-separable degrees of freedom GT: 92
 Number range WS: 256
 Numbers (internal representation of) ... PL: 28
 Numeric keypad UG: 86, 99

O

Object file WS: 330
 PL: 3, 7
 Object module WS: 302, 330
 On-line devices WS: 8
 Opcodes (Assembler) WS: 275
 OPEN (files) WS: 50, 51, 60
 Operating parameters (Datacomm) ... PL: 126
 Operating system kernel WS: 390
 OPTIONS module (CTABLE) WS: 431
 Ordinal range of sets WS: 256
 Other manuals WS: 1, 2
 OTHERWISE (clause of CASE statement)
 WS: 244
 Output:
 Characters PL: 48
 Data types supported PL: 45
 Definition of PL: 22
 Formatted PL: 50-1
 Free-field PL: 45-50
 General PL: 45
 Real numbers PL: 46
 Strings PL: 47
 Words PL: 48
 OUTPUT_ESC procedure
 GT: 39, 55, 82, 85, 278
 Overlap transfers PL: 74
 Overview WS: 1
 Overview of manual PL: 1
 Overwriting files UG: 144
 OVFLCHECK (Compiler option) WS: 214

Programs:

Backing up	UG: 202
Creation	UG: 125, 156, 188
Editing environment	UG: 133
Listings	UG: 158, 193, 257
Permanently loading	UG: 120, 232
Running	UG: 114, 119, 161, 197, 200, 258
	WS: 13
Prompt recognition (Datacomm)	PL: 132
Prompts:	
Aborting	UG: 46, 218
Date	WS: 19
Debugger	WS: 338
Default values	UG: 46, 219
Editor	WS: 67
Filer	WS: 122
Main Level	WS: 4
Responding to	UG: 45, 218
Straight question type	UG: 45, 218
Time	WS: 19
Value range type	UG: 46, 219
Yes/No type	UG: 46, 218
Protocol (Datacomm)	PL: 118, 128
Protocol (Serial)	PL: 158
PSE key	UG: 103
Pulse-mode handshakes (GPIO)	PL: 191
PUT (files)	WS: 53

q

Quantizable degrees of freedom	GT: 93
Question mark wildcard ...	UG: 169, 246, 250
Questions (prompts)	UG: 45, 218
Queue	WS: 340
Quit command:	
Editor	WS: 108
Filer	WS: 166
General	UG: 214
Librarian	WS: 325

r

RAM memory	WS: 23
RAM memory map	WS: 520
RAM volumes	UG: 122, 173, 190, 233
RAND (function)	PL: 12
RANDOM (procedure)	PL: 12
Random access files	WS: 54
RANGE (Compiler option)	WS: 218
Range of addresses	WS: 520
Range of device selectors	PL: 39
Range of numbers	WS: 256
Range of select codes	PL: 38
Raster images, dumping	GT: 82
Ratio, aspect	GT: 34, 60, 98
RCL key	UG: 108
READ (files)	WS: 52
READDIR (files)	WS: 54
Reading buffers	PL: 70
REAL:	
Internal representation	PL: 29
Range of	WS: 256
RECALL key	UG: 74, 96
RECOVER	PL: 62
Rectangular coordinates	GT: 6
REF (Compiler option)	WS: 219
REF tables	WS: 331
Reference Pointer	WS: 331
References, color	GT: 139
Registers:	
Common definitions	PL: 60
Datacomm	PL: 145
General	PL: 59
GPIO	PL: 204
Hardware vs. I/O System	PL: 59
HP-IB	PL: 99
Serial	PL: 169
Relaxed typechecking (Compiler) ...	WS: 231
RELEASE (procedure)	PL: 13
RELEASE and MARK	WS: 236
Remote enable (HP-IB)	PL: 91
Remote message (HP-IB)	PL: 84
Remote state (HP-IB)	PL: 89
Remove command (Filer)	UG: 149, 249
	WS: 167
Removing files	UG: 149, 249
	WS: 138
Removing flexible discs	UG: 13
Renaming BOOT files	WS: 418
Renaming files	UG: 149, 251, 252
	WS: 137

S

Replace command (Editor) WS: 110
 RESET (files) WS: 51, 60
 Reset key UG: 80
 RESET key UG: 95
 Reset:
 Datacomm PL: 128
 GPIO PL: 198
 HP-IB PL: 99
 Serial PL: 160
 Resolution of color models GT: 126
 Resource PL: 43
 Responding to prompts UG: 45, 218
 Retrieving and storing images GT: 68
 Return key UG: 78
 REWRITE (files) WS: 50, 51, 60
 RGB color model GT: 102, 107, 126
 RGB interface GT: 84
 RND module PL: 12
 ROM WS: 389
 ROM addresses WS: 520
 ROM memory map WS: 521
 Roman 8 character set UG: 85
 Rotation of labels GT: 17
 Rotation, label GT: 48
 RS-232 Serial:
 98626 interface PL: 155
 98644 interface PL: 155, 181
 Built-in (Models 216 and 217) PL: 184
 Introduction PL: 155
 UART PL: 155
 RS-232C cable signals (Datacomm) PL: 143
 RST key UG: 107
 Rubber echoes GT: 97
 Run command (Main Level)
 UG: 119, 197, 200, 259
 WS: 13
 RUN key UG: 92, 104
 Run light (System devices) PL: 244
 Run-time errors WS: 551, UG: 198
 Running demonstration programs GT: 4
 Running programs UG: 197, 200
 Running stored programs
 UG: 114, 119, 161, 258

SAMPLE_LOCATOR procedure GT: 292
 Saturation GT: 103
 Save command (Filer) UG: 143
 WS: 169
 SAVE_CONST (Compiler option) WS: 220
 Scaling GT: 9
 Scaling, isotropic GT: 59
 SCANSTUFF module (CTABLE) WS: 442
 Screen dumps GT: 82
 WS: 340
 Screen organization UG: 64
 SEARCH (Compiler option) WS: 221
 PL: 6
 SEARCH_SIZE (Compiler option) WS: 222
 Secondary addresses (HP-IB) PL: 84
 Secondary channel (Datacomm) PL: 142
 Secondary DAMs WS: 405
 SEEK (files) WS: 54
 Segmentation:
 Calling a procedure PL: 299
 Calling a program PL: 297
 Checking a procedure variable PL: 300
 Errors PL: 304
 Free space PL: 297
 Initialization PL: 297
 Introduction PL: 295
 Searching for a procedure name PL: 300
 Unloading segments PL: 303
 Using the explicit code area PL: 301
 Using the heap PL: 302
 Using the stack PL: 297
 WARNING - You're on your own PL: 297
 SEGMENTER module PL: 17
 Select codes PL: 38, 43
 Select key UG: 65, 79
 Selecting the graphics display device GT: 6
 Self-test (during boot) WS: 389
 Self-test (Serial) PL: 167
 Send command (HP-IB) PL: 98
 Separability (degrees of freedom) GT: 88
 Separable degrees of freedom GT: 92
 Serial interfaces PL: 26, 44
 SERIAL modules PL: 35, 38
 Serial printers UG: 47
 WS: 403
 Serial transfers PL: 72
 Serial:
 98626 interface PL: 155
 98644 interface PL: 155, 181
 Baud rate PL: 157, 160
 Break messages PL: 165

UG: *Pascal 3.0 User's Guide*

WS: *Pascal 3.0 Workstation System*

PL: *Pascal 3.0 Procedure Library*

GT: *Pascal 3.0 Graphics Techniques*

- Built-in (Models 216 and 217) **PL:** 184
- Cable options **PL:** 177
- Character format **PL:** 156, 158, 161
- Data input **PL:** 163
- Data output **PL:** 162
- DCE cable **PL:** 178
- DTE cable **PL:** 177
- Error handling **PL:** 163
- Handshake **PL:** 158, 166
- HP 98644 differences **PL:** 181
- Initializing the connection **PL:** 160
- Interface reset **PL:** 160
- Introduction **PL:** 155
- IOREAD_BYTE and IOWRITE_BYTE registers **PL:** 168, 173
- IOSTATUS and IOCONTROL registers **PL:** 169
- Loopback **PL:** 167
- Models 216 and 217 differences . . . **PL:** 184
- Modem handshake **PL:** 161
- Modem line control **PL:** 166
- Modem status and control **PL:** 157
- Modem-line handshakes **PL:** 166
- Parity **PL:** 158, 161
- Parity bit **PL:** 156
- Programming techniques **PL:** 159
- Self-test **PL:** 167
- Signal functions **PL:** 177
- Software handshake **PL:** 158, 161, 165
- Special applications **PL:** 165
- Special characters **PL:** 165
- Start bit **PL:** 156
- Status-Line Disconnect switches . . . **PL:** 157
- Stop bits **PL:** 156
- Transferring data **PL:** 162
- Service request (HP-IB) **PL:** 92
- Service requested state (HP-IB) **PL:** 89
- Set command (Editor) **WS:** 113
- Set environment command **UG:** 133
- SET_ASPECT procedure **GT:** 11, 14, 33, 294
- SET_CHAR_SIZE procedure **GT:** 16, 44, 46, 50, 296
- SET_COLOR procedure **GT:** 99, 114, 297
- SET_COLOR_MODEL procedure **GT:** 101, 300
- SET_COLOR_TABLE procedure **GT:** 55, 101, 114, 302
- SET_DISPLAY_LIM procedure **GT:** 24, 33, 306
- SET_ECHO procedure **GT:** 98
- SET_ECHO_POS procedure **GT:** 309
- SET_LINE_STYLE procedure **GT:** 57, 311
- SET_LINE_WIDTH procedure **GT:** 319
- SET_LOCATOR_LIM procedure **GT:** 98, 315
- SET_PGN_COLOR procedure **GT:** 99, 114, 320
- SET_PGN_LS procedure **GT:** 323
- SET_PGN_STYLE procedure **GT:** 75, 327
- SET_PGN_TABLE procedure **GT:** 328
- SET_TEXT_ROT procedure **GT:** 17, 48, 331
- SET_TIMING procedure **GT:** 332
- SET_VIEWPORT procedure **GT:** 14, 34, 37, 334
- SET_WINDOW procedure **GT:** 9, 14, 34, 35, 47, 59, 336
- Shading graphs **GT:** 78
- SHIFT key **UG:** 98, 110
- Shift key **UG:** 84
- Signal functions:
 - Datacomm **PL:** 143
 - Serial **PL:** 177
- SinAspect program **GT:** 12, 199
- SinAxes1 program **GT:** 22, 200
- SinAxes2 program **GT:** 26, 204
- SinClip program **GT:** 24, 209
- Single stepping a program **WS:** 339
- SinLabel1 program **GT:** 15, 213
- SinLabel2 program **GT:** 16, 18, 214
- SinLabel3 program **GT:** 19, 215
- SinLine program **GT:** 8, 216
- SinViewpt program **GT:** 216
- SinWindow program **GT:** 10, 217
- Skipping data (during input) **PL:** 57
- Slow program execution **WS:** 339
- Software **PL:** 21
- Software handshake:
 - Datacomm **PL:** 131
 - Serial **PL:** 158, 161, 165
- Software memory map **WS:** 525
- Solution vector **GT:** 118
- Source (of I/O operations) **PL:** 22
- Source file **PL:** 3
- Source program **WS:** 180
- Source text **PL:** 6
- Special configurations:
 - Definition of **WS:** 387
 - Examples **WS:** 399
 - Examples of **WS:** 388
 - Introduction **WS:** 387
- Special purpose lines (GPIO) **PL:** 202
- Special transfers **PL:** 76
- Specifying files **UG:** 44, 224
- Speed, pen **GT:** 86

SRM:

- Access rights WS: 63, 128
- Concurrent file access. WS: 61
- Configuration requirements. WS: 403
- Creating a directory WS: 133
- Current working volume WS: 44
- Default volume WS: 44
- Directories WS: 42
- Directory configuration. WS: 454
- Directory structure WS: 42
- Example configuration WS: 451
- File names WS: 35
- File notation WS: 43
- Hardware setup WS: 451
- Installing driver modules WS: 453
- LOCKABLE files. WS: 61
- Multi-disc. WS: 463
- Multiple unit numbers WS: 444
- Overview of installation WS: 452
- Passwords WS: 63
- Unit numbers WS: 43
- Volumes. WS: 43
- Stack (How Pascal uses it). WS: 246
- Stack frame (Debugger). WS: 348
- STACKCHECK (Compiler option)
 - WS: 223, 246, 247
- Standard auto-configuration WS: 393
- Standard configurations (definition of) WS: 387
- Standard modules PL: 12
- Standard partitioning, hard discs. . . . WS: 436
- Start bit:
 - Datacomm PL: 118
 - Serial PL: 156
- STARTUP file. WS: 391, 418
- Static and dynamic links (Debugger) WS: 353
- Static links (Compiler) WS: 251
- Status (HP-IB) PL: 83
- Status indicator (CRT) UG: 65
- Status-Line Disconnect switches (Serial) PL: 157
- STEP key UG: 74, 92, 104
- Stop bits:
 - Datacomm PL: 123
 - Serial PL: 156
- STOP key. UG: 4, 96, 107
- Stop key UG: 64, 81
- Stopping. UG: 4
- Storage-order directory listing UG: 144
- Storing a workfile UG: 143
- Storing and retrieving images. GT: 68
- Straight question prompts UG: 45, 218
- Stream command (Main Level). WS: 14
- Stream files WS: 89, 392, 420
- String length WS: 256
- Strings and textfiles. WS: 58
- STRLEN procedure. GT: 17
- STRWRITE procedure GT: 25
- Subranges (16-bit) WS: 256
- Subsystems:
 - Definition UG: 61
 - Exiting UG: 214
 - General WS: 4
 - Loading UG: 212
 - Memory requirements UG: 267
 - Permanently loading. UG: 120, 171, 232
- Suffix suppression (of file names) . . . UG: 115
 - WS: 37
- Summary of bus sequences (HP-IB) . . . PL: 113
- Summary:
 - Debugger commands. WS: 361
 - Editor commands WS: 90
 - Filer commands WS: 140
 - Librarian commands. WS: 323-5
- Supported features (System devices) . . PL: 210
- Suppressing file suffixes UG: 115
 - WS: 37
- SWITCH_STRPOS (Compiler option) WS: 224
- Symbols (Assembler) WS: 275
- Syntax diagrams (explanation) WS: 6
- Syntax errors. UG: 193
- SYSGLOBALS. PL: 211
- SYSPROG (Compiler option) . . . WS: 225, 229
 - PL: 62
- System addresses WS: 525
- System Boot files. WS: 390, 399
- System BOOT files, renaming. WS: 418
- System configuration table UG: 49, 52
- System controller (HP-IB). PL: 78, 83
- System date, setting. UG: 24, 210
- System devices:
 - Battery commands. PL: 285
 - Battery features PL: 282
 - Beeper. PL: 217
 - Bit-mapped display parameters PL: 237
 - Changing display parameters PL: 237
 - Clock. PL: 219
 - Cursor control. PL: 238
 - Date and time. PL: 219
 - Debugger window PL: 245
 - Direct clock access PL: 222
 - Display. PL: 234
 - Display control characters PL: 234
 - Display parameters. PL: 236

Display status area	PL: 243
Display types.	PL: 234
Dumping the display	PL: 238
Example programs	PL: 211
Hooks	PL: 213
Interrupt masks.	PL: 215
Interrupt processing overview	PL: 213
Interrupts (enabling).	PL: 215
Introduction	PL: 209
ISR.	PL: 214
Key actions	PL: 270
Key buffer	PL: 256
Key buffer I/O hooks	PL: 257
Key codes	PL: 267
Key translation hook	PL: 259
Keyboard	PL: 250
Keyboard ISR hook	PL: 253
Keyboard poll hook	PL: 254
Keyboard request hook	PL: 251
Keyboard types	PL: 250
Keyboards.	PL: 266
Knob	PL: 264
Language table.	PL: 262
Language types	PL: 250
Last line of display	PL: 240
Menus	PL: 242
Missed timer interrupts.	PL: 228
Module	PL: 211
Periodic timer	PL: 230
Powerfail.	PL: 282
Run light	PL: 244
Simplified debugger window.	PL: 249
Supported features.	PL: 210
SYSDEVS source listing	PL: 288
System timer example	PL: 232
Timer ISR	PL: 227
Timer operations	PL: 225
Timers	PL: 224
Toggle alpha/graphics	PL: 235
Tone generator.	PL: 217
Typing aids program	PL: 273
WARNING-You're on your own	PL: 209
System discs	WS: 389
System File Table.	WS: 11, 20
System files	WS: 11, 20, 417
System history	WS: 506
System key	UG: 71
System Library:	
Adding modules to it	PL: 9
	WS: 310
Building your own	PL: 18
	WS: 312
Defined.	WS: 307, 332
	PL: 6
Volume size considerations	WS: 309
	PL: 8, 18
When used by Compiler	WS: 305
	PL: 6
When used by loader	
.	WS: 7, 11, 12, 21, 307
	PL: 7
	GT: 4
System programming (extensions)	WS: 229
System time, setting.	UG: 25, 210
System version	WS: 18
System volume:	
Bubble cards as	WS: 472
EPROMs as.	WS: 482
General	
.	UG: 118, 123, 141, 174, 191, 234
	WS: 11, 21, 125
How chosen	WS: 398
Purpose of.	WS: 28
Search algorithm.	WS: 440
SRM.	WS: 459
SYSTEM.P file	WS: 390, 399, 418
SYSTEM volume	UG: 152
	WS: 393-4, 443
System files	WS: 389
SYSVOL volume	UG: 268

t

Tab key	UG: 84
TAB key	UG: 98, 110
TABLE program:	
BRSTUFF module	WS: 442
CTABLE source file	WS: 430
CTR module	WS: 441
Failures of	WS: 398
General	WS: 8, 388, 391
Modifying	WS: 429
OPTIONS module	WS: 431
Renaming	WS: 418
SCANSTUFF module	WS: 442
TABLES (Compiler option).	WS: 226
Talk addresses (HP-IB)	PL: 81

Tape drives:	
Access methods	WS: 497
Backup utility	WS: 498
Certify	WS: 502
File System access	WS: 503
Introduction.	WS: 497
List of supported devices	WS: 497
Media-copy	WS: 500
Selective backup.	WS: 504
Terminology	WS: 498
Verify.	WS: 501
Volume backup	WS: 504
Target vector	GT: 118
Telephone links (Datacomm)	PL: 135
Terminal identification (Datacomm)	PL: 134
Terminal prompt messages (Datacomm)	
.	PL: 140
Terminating transfers	PL: 74
Terminology	PL: 21
Test program	GT: 89, 94
Text.	GT: 132
Text files:	
Creating	WS: 67, 68
Declaration	WS: 56
I/O	WS: 56
Representation	WS: 56
Strings	WS: 58
Structure of	WS: 88
Text record	WS: 332
Text, writing to graphics screen	GT: 15
Tick marks	GT: 20, 62
Time, setting system.	UG: 25, 210
Timeouts:	
General.	PL: 61, 65
Printers	WS: 402, 433
Datacomm	PL: 130
Timers (System devices)	PL: 224
Timing compatibility.	PL: 24
Tone generator (System devices).	PL: 217
Total available memory	UG: 121
Transfers:	
END condition	PL: 76
Introduction.	PL: 69
Match character	PL: 76
Overlap	PL: 74
Serial	PL: 72
Special.	PL: 76
Termination of	PL: 74
Word	PL: 76
Translate command.	UG: 153, 260
Translate command (Filer)	WS: 38, 129, 170
TRAP instruction (68000).	WS: 247, 269

Triggering (HP-IB)	PL: 86
TRY/RECOVER	PL: 62
	WS: 229, 551
Type-ahead buffer	UG: 66, 88, 101, 112
	PL: 256
Typing-aids program (System devices)	PL: 273

u

U.S. ASCII characters.	WS: 528-9
U.S./European display characters . .	WS: 530-3
UART (RS-232 interface)	PL: 155
UCSD (Compiler option).	WS: 227
UCSD supported features	WS: 239
UCSD Unit I/O operations.	PL: 13
UIO module	PL: 13
Unassemble commands (Librarian)	WS: 318-21
Unblocked devices	WS: 394
Unit directory command (Filer).	WS: 172
Unit I/O operations.	PL: 13
Unit numbers:	
Defined	WS: 27
General.	WS: 8, 9, 11
How assigned	UG: 47, 225, 226
Standard assignments	WS: 394
Standard assignments	WS: 393
Unit Table	WS: 8, 9, 27, 393
Unit:	
Default unit number	UG: 151
Description of	UG: 39
Prefixing to a unit number	UG: 151
Relationship to volumes.	UG: 40
Unit number	UG: 39, 44, 47, 224
Winchester (hard) discs	UG: 48
UNITBUSY (function)	PL: 13
UNITCLEAR (procedure)	PL: 13
UNITREAD (procedure)	PL: 13
Units (blocked vs. unblocked).	WS: 27
Units (UCSD)	WS: 245
UNITWAIT (procedure).	PL: 13
UNITWRITE (procedure).	PL: 13
Unlisten and untalk messages (HP-IB) . .	PL: 83
UNLK instruction (68000).	WS: 248
User key.	UG: 71
User restart command (Main Level)	
.	UG: 30, 119, 259
.	WS: 17
User-defined keys	UG: 77
Using the stack	WS: 273

UG: *Pascal 3.0 User's Guide*
WS: *Pascal 3.0 Workstation System*
PL: *Pascal 3.0 Procedure Library*
GT: *Pascal 3.0 Graphics Techniques*

V

- Value range prompts UG: 46, 219
- Variable size (determining) WS: 230
- Variables, global WS: 12, 17, 19
- Variables, zeroing WS: 12, 17
- Vector, color GT: 118
- Verify command (Editor) WS: 117
- Version Command (Main Level) UG: 121
WS: 18
- Viewport, defining GT: 13, 34
- Virtual coordinates GT: 13
- Vision, color GT: 133
- Vols command UG: 48, 50, 59, 152, 255
- Volume ID UG: 38
WS: 31
- Volume:
 - Changing a volume name UG: 148, 252
 - Compacting free space UG: 150, 255
 - CONSOLE UG: 152
 - Contents of system volumes UG: 268
 - Copying entire UG: 248
 - Default volume UG: 117, 151, 176, 236
 - Description of UG: 37
 - Directory UG: 38
 - Listing on-line volumes UG: 152, 255
 - Memory UG: 122, 173, 233
 - On-line UG: 152, 255
 - Prefix volume UG: 151
 - PRINTER UG: 152
 - RAM UG: 122, 173, 233
 - Relationship to units UG: 40
 - Removable UG: 39
 - System volume UG: 118, 123, 141, 174, 234
 - SYSTEM UG: 152
 - Volume ID UG: 38, 44, 50, 224
 - Zeroing UG: 29, 34, 35
- Volumes command (Filer)
 - UG: 48, 50
59, 152, 255
WS: 26, 123, 174
- Volumes on-line, listing UG: 152, 255
- Volumes:
 - Backing up WS: 131
 - Default Volume WS: 28
 - Defined WS: 26
 - General WS: 26
 - Pascal WS: 26
 - Prefix Volume WS: 28
 - PRINTER WS: 403
 - Renaming WS: 137
 - Syntax of specifier WS: 31, 143
 - System Volume WS: 28

W

- WARN (Compiler option) WS: 228
- What command (Main Level)
 - UG: 116, 174, 234
WS: 20
PL: 6, 9
GT: 4
- What command (Filer) WS: 175
- Where the buffers low roam PL: 69
- Wildcards UG: 148, 167, 169, 202, 245, 250
WS: 38, 129
- Winchester disc:
 - Autostart file UG: 180
 - Booting from UG: 170
 - Copying Pascal system UG: 166, 230
 - Formatting UG: 30, 222
 - Initialization UG: 30, 222
 - Unit number assignments UG: 50, 226
- Window frame, drawing GT: 37
- Window limits, calculating GT: 35
- Words PL: 27, 48, 56
- Word transfers PL: 76
- Workfile:
 - Clearing UG: 152, 245
 - Compiling UG: 161, 189, 196, 199
 - Creation UG: 136, 142, 241, 242
 - Decision to use UG: 187, 188
 - Deleting UG: 152
 - Description of UG: 140
 - Running a program UG: 119, 197, 200
 - Saving UG: 143, 188, 200, 240, 243
 - Updating in Editor UG: 136
- Workfiles WS: 88, 139, 183
- World coordinates GT: 13, 226, 227
- WRITE (files) WS: 52
- Write-protection (flexible discs) UG: 52
- WRITEDIR (files) WS: 55
- WRITELN procedure GT: 25
- Writing data PL: 45
- Writing modes GT: 127
- Writing text to graphics screen GT: 15
- Writing to buffers PL: 71
- WS1.0 file names WS: 35

X

Xchg command UG: 129

Y

Yes/No prompts UG: 46, 218

Z

Zap command (Editor) WS: 120

Zero command (Filer) UG: 35

WS: 176

Zeroing a volume . . . UG: 29, 34, 35, 221, 223

MANUAL COMMENT SHEET

Pascal 3.0 Documentation Guide and Master Index

for the HP 9000 Series 200

98615-90015

April 1985

Update No. _____

(See the Printing History in the front of the manual)

Name: _____

Company: _____

Address: _____

Phone No: _____

fold ----- fold

Programming Experience: _____

System Configuration: _____

Comments: _____

fold ----- fold



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 37 LOVELAND, COLORADO

POSTAGE WILL BE PAID BY ADDRESSEE

Hewlett-Packard Company
Fort Collins Systems Division
Attn: Customer Documentation
3404 East Harmony Road
Fort Collins, Colorado 80525

